BREAD BIN USER INSTRUCTIONS

MONDEX Anna i Jerzy Affek Spółka Jawna with its registered office in Olsztyn (10-416) at ul. Towarowa 17, entered in the register of entrepreneurs kept by the District Court in Olsztyn, 8th Commercial Division of the National Court Register, under KRS number 0000005755, NIP: 7391010198.
Customer Service Department: support@mondex.pl

Thank you for purchasing our bread bin. To ensure its long-lasting use and to keep your bread fresh, please read the following guidelines on use and care.

1. Safety in use

- **Stable positioning:** Make sure the bread bin is placed securely on a kitchen worktop or shelf. Do not place heavy objects on it, as they may cause it to tip over or damage the lid.
- **Keep away from children:** The bread bin should be placed out of the reach of small children, to avoid accidental opening and trapped fingers.

2. Use

- **Storing bread:** The bread bin is intended for storing bread products such as loaves, rolls, baguettes and other baked goods. To keep bread fresh, place it in the bread bin without additional packaging or in paper bags that allow air to pass through.
- **Ventilation:** Bread bins are usually fitted with ventilation openings, which ensure adequate air circulation and prevent the bread from going mouldy. Make sure the openings are not blocked.
- **Daily care:** Open the bread bin regularly to check the condition of the bread. Remove any crumbs that may collect at the bottom of the bread bin to avoid mould and unpleasant odours.

3. Care and maintenance

- **Cleaning:** The bread bin should be cleaned regularly to maintain hygiene and keep the stored bread fresh. Wash the bread bin by hand, using a mild detergent and a soft cloth. Avoid abrasive sponges, which may scratch the surface of the bread bin, especially if it is made of wood or lacquered metal.
- **Drying:** After washing, the bread bin must be dried thoroughly before you put bread in it. Moisture may encourage the growth of mould and affect the quality of the stored bread.
- **Avoiding extreme temperatures:** Do not expose the bread bin to direct sunlight or place it near heat sources such as a cooker or oven. Extreme temperatures may cause the material to warp or damage the protective coating.

4. Final notes

- **Warranty:** Our bread bins are covered by a quality warranty. If you find manufacturing defects or mechanical damage, please contact our customer service department.
- **Protecting the material:** To maintain the appearance and functionality of the bread bin, avoid placing heavy objects on it and regularly remove accumulated crumbs.

Thank you for choosing our bread bin. We hope it will serve you for many years, helping to keep your bread fresh.