INSTRUCTIONS FOR USE OF DECORATIVE ITEMS

MONDEX Anna i Jerzy Affek Spółka Jawna, with its registered office in Olsztyn (10-416) at ul. Towarowa 17, entered in the register of entrepreneurs kept by the District Court in Olsztyn, 8th Commercial Division of the National Court Register, under KRS number 0000005755, NIP: 7391010198.
Customer Service Department: support@mondex.pl

Thank you for purchasing our decorative items. To ensure their long-lasting use and to preserve their appearance, please read the following guidance on use and care.

1. Safety of use

- **Installation and stability:** Before installing decorative items such as mirrors, clocks or frames, make sure they are firmly fixed to the wall or surface. Use suitable screws, wall plugs and brackets to avoid falling and damage. Trays should be placed stably on a flat surface.
- **Keep away from children:** Decorative items, especially those made of glass or with sharp edges, should be placed out of the reach of small children to prevent accidental injury or breakage.
- **Avoiding overloading:** Do not overload decorative trays or shelves on which frames or clocks are placed. Excessive weight may cause them to become damaged or to tip over.

2. Use

- **Photo frames:**
  - **Inserting photos:** Place the photo inside the frame gently, taking care not to scratch the glass or damage the photograph. Check the condition of the frame and the glass regularly to avoid the build-up of dust and dirt.
  - **Wall mounting:** If the frame is intended to be hung on a wall, make sure it is properly secured to prevent it from falling.
- **Wall and standing clocks:**
  - **Maintenance of the movement:** Check regularly that the clock movement is working correctly. Replace the batteries as needed and, in the case of mechanical clocks, wind them appropriately.
  - **Installation:** Wall clocks should be mounted on stable surfaces of sufficient strength. Make sure the hangers are firmly fixed.
- **Decorative trays:**
  - **Use:** Decorative trays may be used to display various items, such as candles, vases or small figurines. Make sure that the items placed on the tray are evenly distributed to prevent it from tipping over.
  - **Cleaning:** Trays should be cleaned regularly with a soft, damp cloth to remove dust and dirt. Avoid harsh cleaning agents, which may damage the surface of the tray.
- **Mirrors:**
  - **Installation:** Mirrors should be mounted on solid walls, using suitable brackets and wall plugs. Make sure the mirror is stably fixed to prevent it from falling.
  - **Cleaning:** Use a special glass cleaner to remove streaks and dust from the surface of the mirror. Avoid spraying liquid directly onto the mirror – it is best to apply the cleaning product to a cloth and then wipe the surface.

3. Care and maintenance

- **Cleaning:**
  - **Regular dusting:** To preserve the appearance of decorative items, dust their surfaces regularly using a soft cloth or a dusting brush. Avoid using rough materials, which may scratch the surface.

    - **Avoiding moisture:** Most decorative items are not moisture-resistant. Avoid placing them in areas of high humidity, such as bathrooms, unless they are designed for such use.
- **Protection from sunlight:** Direct sunlight may cause colours to fade and materials to deteriorate. Place decorative items away from windows if they would be exposed to prolonged sunlight.
- **Checking fixings:** Regularly check that the fixings of decorative items, such as frames or mirrors, are in good condition and do not need tightening or replacing.

4. Final notes

- **Warranty:** Our decorative items are covered by a quality warranty. If you find any manufacturing defects or mechanical damage, please contact our customer service department.
- **Preserving appearance:** To preserve the appearance and functionality of decorative items, avoid using harsh cleaning agents and overloading decorative objects.

Thank you for choosing our products. We hope that our decorative items will add charm and style to your interiors.